



carbon by design

2613 Temple Heights Drive • Unit E • Oceanside • CA • 92056

Lic. Trim INSTALLATION



Adhesive Promoter:

With all 3M VHB Taped Products we supply an ampule of adhesion promoter. This tube of adhesion promoter must be used anywhere the tape will come into contact with. To use the ampule crack it in the middle, you will hear the noise of breaking glass. Quickly wipe the ampule on all of the surfaces until it goes dry. Do not attempt to wait to rub the ampule on each side, it will evaporate, you can rub the ampule and place the tape on the surface up to one hour latter.



Peeling the Tape:

The trick with the 3M tape is you only get one shot at placement. Ideally you would like to place the part where you want it and then remove the tape. To do this attach masking tape to the red backing. Place the part where you want it and pull the masking tape to free the red backing on the 3M Tape. If this doesn't work try to barely start removing the red backing to assist the masking tape in pulling off the red backing. Once removed firmly press down on the part for one minute. If applied correctly the tape will never pull apart.

Lic. Trim INSTALLATION



Adhesive Promoter:

With all 3M VHB Taped Products we supply an ampule of adhesion promoter. This tube of adhesion promoter must be used anywhere the tape will come into contact with. To use the ampule crack it in the middle, you will hear the noise of breaking glass. Quickly wipe the ampule on all of the surfaces until it goes dry. Do not attempt to wait to rub the ampule on each side, it will evaporate, you can rub the ampule and place the tape on the surface up to one hour latter.



Peeling the Tape:

The trick with the 3M tape is you only get one shot at placement. Ideally you would like to place the part where you want it and then remove the tape. To do this attach masking tape to the red backing. Place the part where you want it and pull the masking tape to free the red backing on the 3M Tape. If this doesn't work try to barely start removing the red backing to assist the masking tape in pulling off the red backing. Once removed firmly press down on the part for one minute. If applied correctly the tape will never pull apart.